

EN

INSTALLATION INSTRUCTION

Split version:

1. Press sleeve against the wall, centre assembled sleeve with support of seal on the pipe and mark drilling holes.
2. Remove sleeve and seal from the wall and bore holes.
3. Apply included sealing compound on the backside of sleeve (in thick stripes $\varnothing 6 - 10$ mm), one stripe between the outside edge of flange and screwhole. An other one between welded sleeve and screwhole. Put last stripe around the screwhole.
4. In this assembly step, first the seal and then the pre-construction sleeve is placed on the pipe. Then the two half-shells are connected with the supplied screws. The sealing rubber inserts are placed on the sealing flanges so that they are flush with the inner edge of the sleeve tube. Subsequently, the pre-construction sleeve can be screwed to the wall (sealing rubber inserts, sealing adhesive, screws and dowels are included). Spread the emerging sealing adhesive.
5. Tighten screws of the sealing (see application manual of sealing).

