

EN
INSTALLATION INSTRUCTION

KO sleeve

1. Remove the protective foil from both adhesive surfaces.
2. Place the KO sleeve around the carrier pipe. Put the adhesive surfaces on top of each other. Press the seam with high pressure for approx. 5 minutes.



KG/KO sleeve

3. Pull the large end of the sleeve onto the casing pipe. Fold in the sleeve and secure the ends with stainless steel straps.



KG/KO sleeve

If the sleeve diameter is too small for the carrier pipe, the KG or KO sleeve can be cut off on site with scissors (20 mm result in a \varnothing increase of about 13 mm to 20 mm). In doing so, make sure that the sleeve is 2-5 % smaller than the outer pipe diameter in the area of the carrier pipe so that the sleeve adheres crease-free.

